



ETHERNET

7i95t

My DRO is a TTL interface and my earths are commoned so I can put it straight into the 7i95t. I put a male and female DB-9 for each line so the sensors plug into one and the additional cables back to the DRO plug into the other retaining continuity so the DRO just works as normal.

I have arbitrarily numbered the driver module pins so that 1 is nearest to the front panel.

The documentation for the DM556T does not show the pins 7 and 8 (alarm) that are on mine. This makes the pin numbering a bit wierd.

### Wiring for CNC Control Box

Sheet:		File: cnc.kicad_sch	
<b>Title:</b>			
Size: A4	Date:	<b>Rev:</b>	
KiCad E.D.A. kicad 7.0.1		Id: 1/1	